Method of Test for SIEVE ANALYSIS OF MINERAL FILLER DOTD Designation: TR 102M-97

I. Scope

- A. This procedure is intended to determine the particle size distribution of mineral fillers by sieve analysis.
- B. Reference Documents
 - DOTD TR 108, Splitting and Quartering Samples
 - DOTD TR 113, Dry Sieve Analysis of Fine and Coarse Aggregates
 - 3. AASHTO M 92, Wire Cloth Sieves for Testing Purposes
 - 4. DOTD Materials Sampling Manual

II. Apparatus

- A. Balance a balance having a capacity of 1 kg or more, sensitive to 0.1 g
- B. Sieves sieves conforming to AASHTO Designation M92
- C. Drying apparatus
 - Oven an oven capable of maintaining a temperature of 110±5°C
 - 2. Hot plate electric or gas not plate, equipped with a suitable heat dispersing shield, to evenly distribute heat to sample drying pan.
- Note 1: The use of hot plate drying in the field is allowed where ovens are not available.

 Open flame hot plates shall be so equipped as to not allow direct contact of the flame with the drying pan.
 - D. Stirring apparatus a mechanically operated stirring apparatus, including special dispersion cups. The stirring device shall have an electric motor with a no load speed of not less than 10,000 rpm, attached to a vertical shaft fitted with paddles made of metal, plastic, or hard rubber, similar to that shown in Figure 1. Dispersion cups conforming to either design shown in Figure 1 shall be used to contain the sample while it is being dispersed.
 - E. Desiccator Jar or other suitable container with tightly fitting lid, containing waterabsorbing agent, such as silica gel, for allowing samples to cool without absorbing

hygroscopic moisture.

- F. Goggles and face mask/filter
- G. Worksheet Aggregate Test Report, DOTD Form No. 03-22-0745 (Figure 2)

III. Health Precautions

Handling of mineral fillers and similar materials can generate a significant amount of dust. Proper ventilation and the use of goggles and face mask/filters is necessary to ensure personal health as well as for safety compliance.

IV. Sample

Sample shall be obtained in accordance with the DOTD Materials Sampling Manual, and consist of not less than 1500 g of dry material.

V. Procedure

- A. Reduce the size of the sample in accordance with DOTD TR 108 to obtain a representative portion of material of approximately 100 g. Determine and record the mass to the nearest 0.1 g on the worksheet as Initial Dry Total Mass.
- B. Place sample in dispersion cup, and add water until the cup is approximately 2/3 full.
- Mount cup into stirring device and disperse the sample for 5 minutes.
- D. Remove the cup and pour the dispersed sample onto a 53 μ m sieve.
- E. Wash the sample on the sieve with a low velocity water stream, gently agitating the sieve during the washing process.
- F. Continue the washing/agitating process until the wash water is relatively clear.
- G. Place the sieve containing the sample in the oven and dry to constant mass at 110±5°C.
- Note 2: Constant mass for drying purposes is defined as less than 0.1% by mass loss between successive mass determinations no less than 15 minutes apart.
 - H. Remove sample from the oven and place it in the desiccator and allow to cool to room temperature.

- Using the sieve sizes required by the specifications of the particular project, sieve the sample in accordance with DOTD TR 113.
- J. After sieving, determine the mass of the portion of the sample remaining on each sieve and record on the worksheet to the nearest 0.1 g.

VI. Calculations

A. Calculate the percent retained on each sieve (R) to the nearest 0.01 percent using the following formula:

$$R = \frac{A}{W_T} \times 100$$

where:

A = mass of material retained on sieve, g

 W_T = initial mass of sample tested, g 100 = constant, to convert answer to %

example:

A = 0.1 g
W_T = 100.2 g
R =
$$\frac{0.1}{100.2} \times 100$$

= 0.000998 × 100
= 0.0998
R = 0.10

B. Calculate to the nearest 0.01% the percent coarser for each sieve size (C_x) using the following formula:

$$C_{x} = \sum \{R_{x+1} ... R_{x+i}\} + R_{x}$$

where:

R_{x+i} = percent retained on the each sieve used with larger openings than sieve X.

R_v = percent retained on sieve X.

Note 3: For the largest sieve used for a particular sample, the percent coarser equals the percent retained.

example:

 $R_{600} = 0.00$

 $R_{180} = 0.09$

 $R_{75} = 0.49$

 $R_{53} = 1.09$

 $C_{600} = \%$ coarser than the 600 μ m sieve

 $C_{600} = 0.00$

 $R_{600} = 0.00$

and

 $C_{180} = \%$ coarser than the 180 μ m sieve

 $C_{180} = 0.00 + 0.09$

 $C_{180} = 0.09$

and

 C_{75} = % coarser than the 75 μ m sieve

 $C_{75} = 0.00 + 0.09 + 0.49$

 $C_{75} = 0.58$

and

 C_{53} = % coarser than the 53 μ m sieve

 $C_{53} = 0.00 + 0.09 + 0.49 + 1.09$

 $C_{53} = 1.67$

C. Calculate the percent passing (P_x) for each sieve size to the nearest 1% using the following formula:

$$P_x = 100.00 - C_x$$

where:

 C_x = percent coarser than sieve X 100.00 = constant

example:

 $C_{600} = 0.00$

 $C_{180} = 0.09$

 $C_{75} = 0.58$

 $C_{83} = 1.67$

$$P_{600} = 100.00 - 0.00$$
$$= 100.00$$

$$P_{600} = 100$$

$$P_{180} = 100.00 - 0.09$$

= 99.91

$$P_{180} = 100$$

$$P_{75} = 100.00 - 0.58$$

= 99.42

$$P_{75} = 99$$

$$P_{53} = 100.00 - 1.67$$

$$P_{53} = 98$$

VII. Report

Report the Percent Passing (P) each sieve required by the appropriate specifications to the nearest whole percent.

VIII. Normal Test Reporting Time

Normal test reporting time is 3 days.

TOLERANCES FOR STIRRING PADDLES

- (a) diameter 19.05 ± 1.60 mm
- (b) longest diameter 24.76 ± 1.60 mm




Figure 1

Upper: Detail of Stirring Paddle

Lower: Dispersion Cups

ATT MENU SELEC	CTION - 2	Louisiana De	partme	nt of Tren	sportation and Development Rev. 7/95 FEST REPORT
roject No. ate Sampled		222	2	Materia Submit	Code 4.3.9. Lab No. 229.99.16.9. ed By 0.3.0.4. Quantity 50.0.
urpose Code	3 Source Code			Spec C	pde P.O. No
ate Tested	1.0299	6 Ide	nt 🖊	1 <i>E-</i> -	2.69 Plant Code Frict.Rating (1-4)
em No.				Date Re	oc'd (lab) 10/80/96 Sampled By: 70.5.
_					
emarks 1 L				_ 	
ested By	H.S.	Date <u>//</u>	129	196	Checked By Q. B. 20. Date 11/81/96
	DOTD TR 102, 112, 113	& 309			DOTD TR 428
۔ 1 ر 1 a	grame 2 = pounds				Liquid Limit Plestic Limit Wt Cup + Wet Soil.g
Sieve		2 1		•4	Wt Cup + Wet Soil,g Wt Cup + Dry Soil,g @
mm in	Wt. Retained	Retained C	oerser	% Passing	Wt Cup + Dry Soil,g, Wt Water
63 2 1/2	<u> </u>				Wt Water Cup No
50 2					Cup No Wt Dry Soil
37.5 1 1/2					Wt Cup, g % Moleture
31.5 1 1/4	1.1.1.1.1				Wt Dry Soil Moisture Plasticity Index
25.0 1					7 monuty muta
19.0 3/4					Absorption (T84 or T85)
16.0 5/8	-				Spec Grav SSD (T84 or T85)
12.5 1/2					Spec Grav APP (TR 300)
9.5 3/8					Effective Spec Gray (TR 300)
1 -					
4.75 No. 4					Opt Moist Content,%(TR 418)
4.75 No. 4 L					Maximum Density (TR 418)
					Maximum Density (TR 418)
Wt Matl.in Pan	*	,	% Diff:		Maximum Density (TR 418) Lab Comp Method (TR 418) Cement, % (TR 432 or SPECIFIED)
Wt Meti.in Pen Acc. Total Initial Dry Total W			% Diff:		Maximum Density (TR 418)
Wt Mati.in Pan I Acc. Total Initial Dry Total W Unit 1 = 1 =	grame 2 = pounds	. ,	% Diff:		Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit, 1 == Sieve		Retained		% Passing	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit	grame 2 = pounds			Passing	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code % Clay Lumps, % (TR 119) Friable Particles, % (TR 119) Clay Lumps & Friable Particles % (TR 119)
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit, 1 = Sieve mm/sm No 2.36 8	grame 2 = pounds			Passing	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit	grame 2 = pounds			Passing	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 416 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit, 1 == Sieve mm/sm No 2.36 8 2.00 10 1.18 16	grame 2 = pounds	Retained	Coerser		Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Agg. Total Initial Dry Total W Unit, 1 = Sleve mm/um No. 2.36 8 2.00 10 1.18 16 600 30	grame 2 = pounds			Passing	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Matl.in Pan Agg. Total Initial Dry Total W Unit	grame 2 = pounds	Retained	Coerser		Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Agg. Tatal Initial Dry Total W Unit	greme 2 = pounds Wt. Retained	Retained (Coarser	/00	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Matl.in Pan Agg. Tatal Initial Dry Total W Unit	grame 2 = pounds	Retained	Coarser		Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Agg. Tatal Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09	Coarser	100	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati,in Pan Agg. Total W Unit	greme 2 = pounds Retained	0.00 0.09	Coarser	100	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Agg. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09	Coarser	100	Maximum Density (TR 418) Lab Comp Method (TR 41a) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 41e or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09	Coarser	100	Maximum Density (TR 418) Lab Comp Method (TR 41a) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code % Clay Lumps, % (TR 119) Friable Particles, % (TR 119) Clay Lumps & Friable Particles % (TR 119) Flat or Elongated Part, % (TR 119) Coal & Lignite, % (TR 119) Glassy Particles, % (TR 119) Iron Ore, % (TR 119) Wood, % (TR 119) Total (Clay Lumps, Fri.Part., Iron Ore, Coal & Lignite, Wood), % (TR 119) Foreign Matter, % (TR 109) Clam Shell, % (TR 110) Soundness, % Loss (T 98) Colorimetric Test (1=Pase, 2=Fail) (T 21) Asphalt Content, % (TR 307)
Wt Mati.in Pan Acc. Total Acc. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09	Coarser	100	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Matl.in Pan Agg. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09 0.49 1.09	Coerser O I	/00 /00 /00 99 98	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Acc. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09 0.49 1.09	Coarser	/00 /00 /00 99 98	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Matl.in Pan Agg. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09 0.49 1.09	Coerser O I	/00 /00 /00 99 98	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 418 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09 0.49 1.09	Coerser O I	/00 /00 /00 99 98	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 416 or SPECIFIED) Other (Additive) Code
Wt Mati.in Pan Acc. Total Initial Dry Total W Unit	greme 2 = pounds Retained	0.00 0.09 0.49 1.09	Coerser O I	/00 /00 /00 99 98	Maximum Density (TR 418) Lab Comp Method (TR 418) Cernent, % (TR 432 or SPECIFIED) Lime, % (TR 416 or SPECIFIED) Other (Additive) Code % Clay Lumps, % (TR 119) Friable Particles, % (TR 119) Clay Lumps & Friable Particles %(TR 119) Fist or Elongated Part, %(TR 119) Coal & Lignite, % (TR 119) Glassy Particles, % (TR 119) Iron Ore, % (TR 119) Wood, % (TR 119) Total (Clay Lumps, Fri.Part., Iron Ore, Coal & Lignite, Wood), %(TR 119) Foreign Matter, % (TR 108) Clam Shell, % (TR 110) Soundness, % Loss (T 104) Abrasion, % Loss (T 90) Colorimetric Test (1 = Pase, 2 = Faib) (T 21) Asphalt Content, % (TR 307) Retained Marshall Stability (TR 313) Resistivity (TR 429) pH (TR 430) Organic Content, % (TR 413)

Figure 2 Aggregate Test Report (02-22-0745)